


Contents of Kit #14



1. 2 plates 6x12
2. 2 cable ties
3. 2 plates 2x12
4. Battery holder for four AA batteries
5. Ready to use electromagnet
6. Heavy duty reed switch (rated 1A @ 110V DC)
7. Piece of sandpaper
8. Safety ring
9. Jumper wire (to experiment with 4 different voltages)
10. ZNR surge absorber
11. 4 plastic sleeves (washers)
12. 2 twist-on connectors
13. 2 long axles (50 mm)
14. 7 neodymium magnets (10 mm x 3 mm, grade N35)
15. 7 double sided sticky foam pads
16. 4 bricks 2x2 with center hole
17. 2 bricks 1x2 with small side hole
18. 2 bricks 1x2 with 2 side holes
19. 4 bricks 1x2
20. 3 bricks 1x1
21. Plate 1x2

Contents of kit #14

This is not a Lego® product even if it contains Lego® bricks and plates. All warranties provided by Simple Motors. LEGO® is a trademark of the LEGO Group of companies which does not sponsor, authorize or endorse this product.

All rights reserved. 2013 Simple Motors, LLC ♦ www.simplemotor.com ♦